


AOM561



1. POWER
Press this button to turn the AOM561 on.
2. BRIGHTNESS - / +
Press brightness (-) button to darken the picture.
Press brightness (+) button to brighten the picture.

WIRING DIAGRAM

1	BLUE	- TRIGGER WIRE
2	EMPTY	
3	RED	- 12V DC
4	BLACK	- GROUND

